

Insert the included spacer as shown  
when mounting the Actuator.

